
LOG SET IMPORTANT INFORMATION






This instruction contains recommended log placement for your Real Fyre log set. This instruction contains recommended log placement for these Real Fyre logs which will promote good combustion and provide superior flame pattern and appearance, when the logs are used with a Peterson burner system. Adequate ventilation is absolutely necessary! Provided significant, noticeable sooting does not occur, some flexibility is possible in log placement to suit your individual preference (see Important below). If you experience a continued accumulation of black carbon (soot) on your logs it is an indication of incomplete combustion and you should move the effected log(s) so as to minimize the flame contact on the effected log(s). Please read these instructions completely and carefully.




Important: Adequate ventilation is absolutely necessary. Adequate spacing between the logs is NECESSARY and MUST be maintained. Some carbon build up (sooting) may occur where flames strike the logs. If carbon build up (sooting) continues, rearrange top logs to allow more opening(s) for flame(s) before sooting becomes worse. If any sooting occurs outside of the firebox (i.e. on the walls), turn off unit immediately and contact a qualified professional service technician.

WARNING: Use ONLY Real Fyre burners and valves with this Real Fyre gas log set. Failure to do so may result in property damage or personal injury, and will void listings, certifications, and invalidate claims made to RHP. Contact your local Real Fyre dealer if you need more information.

This product is only warranted when used as part of a Robert H. Peterson Co. vented burner system.



Charred Grizzly Oak Log Placement Instructions (24" model)





CAUTION: Burn hazard! Logs will remain hot for some time after use.


This instruction is for log placement on a standard grate (as depicted in the images below). If placing this log set on a G47 burner, refer to the specific log placement instructions found in the owner's manual provided with the burner.


This charred log set includes an ember screen and glowing embers. For G4 & G45 Series Burner Systems; refer to the main owner's manual for screen and embers installation. For G46, G47, & "P" Series Burner Systems; DISCARD the screen and embers as they are not applicable.












Charred Grizzly Oak Log Placement Instructions (30" model)


This instruction is for log placement on a standard grate (as depicted in the images below). If placing this log set on a G47 burner, refer to the specific log placement instructions found in the owner's manual provided with the burner.





CAUTION: Burn hazard! Logs will remain hot for some time after use.


This charred log set includes an ember screen and glowing embers. For G4 & G45 Series Burner Systems; refer to the main owner's manual for screen and embers installation. For G46, G47, & "P" Series Burner Systems; DISCARD the screen and embers as they are not applicable.


2 Boxes	Items
CHGO-30B (Bottom logs)	CHD-01, EM-1, CHGOL-30BF, CHMJL-24BR
CHGO-30T (Top logs)	CHBL-13T, CHBL-14T, CHBL-15TL, CHBL-18TR, CHDL-14TC, CHGOL-17T, CHGOL-18T, WWSL-14T












Charred Grizzly Oak Log Placement Instructions (36" model)

This instruction is for log placement on a standard grate (as depicted in the images below). If placing this log set on a G47 burner, refer to the specific log placement instructions found in the owner's manual provided with the burner.



CAUTION: Burn hazard! Logs will remain hot for some time after use.

This charred log set includes an ember screen and glowing embers. For G4 & G45 Series Burner Systems; refer to the main owner's manual for screen and embers installation. For G46, G47, & "P" Series Burner Systems; DISCARD the screen and embers as they are not applicable.

3 Boxes	Items
CHGO-30BR (Rear log)	PNL-30BR
CHGO-36BF (Front logs)	CHD-01, EM-1, CHGOL-36BF
CHGO-36T (Top logs)	CHBL-13T, CHBL-14T, CHBL-18TR, CHGOL-17T, CHGOL-18T, CHGOL-19T, CHGOL-21T, CHMJL-15T



